
































INSTALLATION GUIDE









Parts list







A1	A2	A3	A4	A5	A6	A7	
M5X15	M6X15	M8X25	Ø16XØ6.2X1.5	M8X45	Ø16XØ8.2X1.5	Ø13XØ8.2X13	X4
							
X4	X4	X4	X4	X4	X4	X4	






B1	B2	B3	B4	B5	B6		C1	C2/C3	C4	
3mm	5mm	6mm	M8X10	M8	M8	X1	M8X10	M8X45		X1
										
X1	X1	X1	X34	X17	X17		X14	X8	X8	





D1  1800mm X2	D2  1200mm X1	D3  750mm X2	D4  X4	D5  3" X2	D6  3" X2	
D7  1000mm*2+480mm*4 X6	D8  X4	D9  M5 X4	D10  X16	D11  X8	D12  X4	D13  X4

Installation













20





21 Adjust the vertical position of TV




Height adjustment
10mm



22





Tilt Adjustment $+4^{\circ}/-4^{\circ}$
Adjust the single knob



Depth Adjustment 15mm
Adjust the both knobs

23



Tilt Adjustment $+4^{\circ}/-4^{\circ}$

